



A SENIOR MANUFACTURED
HOME COMMUNITY

FRONT GATE TELEPHONE ENTRY SYSTEM INSTRUCTIONS

Your visitor will find your name and an assigned "CODE NUMBER" on the front gate directory.

When your visitor dials your code number, the entry system will automatically dial your telephone number. Once you have answered the phone call and you have identified your guest, you have the choice to either grant access or deny access to your guest. To grant access to your guest, press 5 on your touch tone phone. The telephone system will respond with a confirmation tone indicating that the gate is opening and will automatically disconnect itself. Some newer phones emit a very short duration tone when the number is pressed. If your phone does this, you may have to press the open number twice in rapid succession to open the gate.

To deny access to your guest, press the # key.

If you are on the phone when a guest tries to contact you from the entry system, they will hear a busy signal and will have to wait for you to end your call before they can contact you.